

Fig. 1




Fig. 2




Fig. 3

4/15

AUTOVEND P.O.S INTERFACE DEMO

FILE CONNECTION VIEW WINDOW

1234567890

DELETE

SND RCV

AUTOVEND

Settings

COM PORT: COM2

☒ DIRECT CONNECTION
☐ MODEM

BAUD RATE:
110
300
600
2400
4800
9600
14400

DIAL-UP NUMBER:

PASSWORD:

ADDRESS BOOK

☒ INVENTORY REPORT
☒ CHANGE FUND REPORT
☒ BUSINESS DAY REPORT
☒ ACTIVITY REPORT

☒ SAVE
X CANCEL

COMM PORT 0

↑↑↑↑

CHECK READER VERSION NR2.03.05A
CHECK READER VERSION NR2.03.05A

PRINT CLEAR

Fig. 4




Fig. 5

6 / 15




Fig. 6

7/15

AUTOVEND P.O.S INTERFACE DEMO

FILE CONNECTION VIEW WINDOW

AUTOVEND

COMM PORT OPENED

PRINTER: ON

CASH MANAGEMENT

PRINTER

FILE SETUP

↑

↑

↑

↑

↔

↔

DIAL-UP

DIAL-UP NUMBER:
93514248

PASSWORD:

ADDRESS BOOK

VIEW: OFF

○ SND

○ RCV

1

2

3

4

5

6

7

8

9

0

MENU

DELETE

PRINT

CLEAR

UNKNOWN DEPOSIT

RCVD FOR CHANGE = 0.00

CHG CONV. TO DEP. = 0.00

TOTAL BRV DEP. =

TOTAL ALL SALES:

=====

0.00

155.00

X CANCEL

X CANCEL

Fig. 7

AUTOVEND P.O.S INTERFACE DEMO

FILE CONNECTION VIEW WINDOW

1

2

3

6

9

DELETE

MAP KEYS

ARROW1

ARROW2

ARROW3

ARROW4

ARROW5

ARROW6

ARROW7

ARROW8

1

2

3

4

5

6

7

8

9

0

MENU

DELETE

✓ SAVE

X CANCEL

CORRESPONDING KEY: F1

COMM PORT C

ND O RCV

CHG CONV. TO DEP. = 0.00

TOTAL BRV DEP. = 0.00

TOTAL ALL SALES: 155.00

PRINT

CLEAR

Fig. 8

AUTOVEND P.O.S INTERFACE DEMO

FILE CONNECTION VIEW WINDOW

1

2

3

4

5

6

7

8

9

MENU

0

DELETE

←

←

←

←

ENTER
PASSCODE:

OK

→

→

→

→

CASH MANAGEMENT SYSTEM

COMM PORT OPENED

PRINTER:ON

PRINT TO: PC PRINTER

PRIVACY VIEW:OFF

X

○ SND

○ RCV

PRINTER

FILE SETUP

UNKNOWN DEPOSITS = 0

RCVD FOR CHANGE = 0.00

CHG CONV. TO DEP. = 0.00

TOTAL BRV DEP. =

TOTAL ALL SALES:

=====

0.00

155.00

PRINT

CLEAR

Fig. 9




Fig. 10

11/15




Fig. 11




Fig. 12

13/15




Fig. 13A




Fig. 13B

Fig. 14

